

## Z-POCKET INSTALLATION

The Z-Pocket can be installed on any BASE canopy, by following this guide.

Use thread size 30 (E-thread) for the stitching. Bartack are 40 points minimum, 2 cm long

1. Stitch the Z-pocket on the trailing edge, leaving the space for the primary stow (stitch on green line)



2. use some pins to keep the Z-pocket centered, and stitch each side following the green line. Make sure you are stitching on the outside part of the internal binding tape, in order to have the stitching as close as possible to the zipper



3. Two bartack must be placed on the trailing edge, in line with the Z-pocket opening



If you have any questions, please contact ADRENALINBASE support :  
[adrenalin@adrenalinbase.com](mailto:adrenalin@adrenalinbase.com)